



QUICK START GUIDE

# FreeLoader Buffer Pedal

## Connections:

- ▶ Input Jack is on top – connect steel guitar here  
Input Jack also powers ON the internal 9v battery  
Remove Input Plug to conserve battery power when not in use
- ▶ Output Jack - connect to input of volume pedal
- ▶ Tuner Out - connect to electronic tuner
- ▶ Leg clip snaps onto most all standard steel guitar legs

## Knob - Variable Impedance Tone Control:

- ▶ Set about halfway and dial in amp tones
- ▶ Use FreeLoader knob to adjust general tone

## Specs:

- ▶ Input Impedance - 15k-1Meg Ohms
- ▶ Battery Life - approx 500 hours with standard alkaline 9v battery
- ▶ Output Impedance - approx 1kOhms
  
- ▶ To replace 9v battery, remove 4 silver screws, pull chassis halves apart, remove old battery, carefully insert new battery and confirm both contact are fully snapped into place for solid contact. Replace cover and screws.